


### Service Bulletin 4812 712 40376

#### MEASURES / PROCEDURE


When drive is replaced, disconnect motor cable pins (see picture and chart below).





# New pin assignment for plug

## Before:



## New:

